

# Installing and uninstalling blaZt USB drivers WIN2K + WINXP



Last revised – Feb 2010

## Contents

How to install drivers for the blaZt USB cable .....	3
How to get the blaZt USB cable to work with Datascan: .....	7
How to uninstall the blaZt USB driver .....	9

## How to install drivers for the blaZt USB cable


To install the blaZt USB drivers you will need the blaZt installation CD that came with the cable or you can download the latest drivers from <http://www.blaZt.biz/downloads/usbdriers.php> and save to a location on your hard drive. You must also have your blaZt USB cable handy for installation.

### *How to install the USB drivers:*


1. Plug in the blaZt USB cable. Windows will come up with a 'found new hardware' wizard to help you install.
2. Check the 'No, not at this time' box and choose 'next'




3. Click 'Install from a list of specific locations' and press 'Next'



4. Click 'Include this location in search' and browse for the file location on the CD at CD:\USB Drivers\FTDI\WinxpWin2kVistaWin7.
5. Click 'next'.



6. After a file transfer screen shows a completed screen will show. Press 'finish' to continue.







7. If a 'Found new hardware wizard' screen appears once more repeat steps 2 to 6.
  
8. You may now set the COM port on your car scan tool software to use the USB cable. Instructions for setting the COM port in Datascan follow.

## How to get the blaZt USB cable to work with Datascan:



1. Plug in USB cable
2. Click on 'Start', then 'My computer'. In the menu on the upper left panel choose 'View system info'.



3. Select the 'Hardware' tab and choose 'Device manager'
4. Click on the '+' next to 'Ports (COM + LPT)' to expand its components
5. Record the COM port number beside 'USB Serial Port'



6. Close the device manager and control panel windows
7. Open Datascan by going to the 'Start' menu and select 'All programs' then 'Nissan Datascan' and click the application icon
8. Go to 'Settings-Communication' menu




9. Set the Com port number to what you recorded in the Device manager (Step 5)
10. Press 'Save'

## How to uninstall the blaZt USB driver

### *Uninstall the USB driver:*

1. Plug the USB cable into any USB port
2. Click on 'Start' then 'My Computer'
3. In the menu on the upper left panel choose 'View system info'
4. Select the 'Hardware' tab and choose 'Device manager'
5. Click on the '+' next to 'Ports (COM + LPT)' to expand its components
6. Right click on 'USB Serial Port (COM#)' and choose 'Uninstall' (Fig. 1)



7. Click 'ok' when asked to confirm device removal.
8. Remove USB cable